

ELEKTRA™
—comfort—

Rechargeable HOT WATER BOTTLE

#HOME
GROUND
ADVANTAGE
ANYWHERE IN THE WORLD



INSTRUCTION MANUAL



SA RUGBY.



OFFICIAL LICENSED PRODUCT

Read these instructions before use and keep them safe. If you pass the appliance on, pass on the instructions too. Remove all packaging, but keep it until you are satisfied.

Important Safeguards


Before connecting the appliance check that the voltage indicated on the label corresponds to the mains voltage in your country.

When using electrical appliances basic safety precautions should always be followed. Please read the following carefully before use:

1. After unpacking, make sure that there are no visible signs of damage.
2. This appliance must only be used as a hot water bottle as indicated in the instructions. Any other use is to be considered hazardous. Selian Agencies C.C. and any of its associate companies cannot be held responsible for any damage or injury that may occur due to improper, incorrect, careless and or negligent use.
3. Do not use with wet hands or feet, or while your body is wet.
4. Do not use the Hot Water Bottle if it is wet.
5. Do not pull the appliance or the power cord to remove the plug from the socket during or after charging.
6. Before cleaning the appliance, make sure that it is cold, and not connected to the power outlet.
7. Should the Hot Water Bottle or protection fuse fail to work properly, unplug it from the power outlet. Contact the Consumer Service Centre for examination and repair.
8. Check the Hot Water Bottle regularly for wear or damage, particularly the charging port.
9. Check the charging cord regularly for wear or damage.
10. The supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.

11. During charging, ensure that the power cord is completely unwound.
12. Your Elektra Hot Water Bottle has been supplied with a charging cord that has been purpose designed short. The Hot Water Bottle must NOT be used while it is charging or plugged in to a power outlet while connected to the charger.
13. The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
14. Children should be supervised to ensure that they do not play with the appliance.
15. Close supervision is necessary when this appliance is used by children, invalids and people sensitive and insensitive to heat.
16. Always allow the appliance to cool down before packing away.
17. Only use the Hot Water Bottle with the charger provided.
18. Do not fold the Hot Water Bottle.
19. Avoid creasing the Hot Water Bottle.
20. Do not iron the Hot Water Bottle.
21. Please follow cleaning instructions carefully so as to avoid injury or damage.
22. This appliance is not designed for medical or hospital use.
23. Keep the Hot Water Bottle away from sharp objects.
24. Do not insert needles or pins into the Hot Water Bottle.
25. Do not use the Hot Water Bottle while it is charging /heating up.
26. Never use the Hot Water Bottle with the charging cord plugged in.
27. Do not use the Hot Water Bottle if it is leaking.

WARNING



Household use only

Additional Safeguards


1. Do not try to repair the appliance yourself. Contact the approved Service Centre for examination and repair.
2. This product has been designed to operate safely when used according to the instruction guide.
3. Do not stand, sit or lie with your weight directly or indirectly on the Hot Water Bottle.
4. It is normal during charging/heating up that the bottle may swell up. To reduce the amount it swells gently shake the Hot Water Bottle once or twice with the charging cord disconnected.
5. If during charging/heating the Hot Water Bottle swells up very badly, unplug, gently shake 3 or 4 times, and after it has cooled down recharge again. If the problem persists, contact the approved Service Centre.

Take care when using this appliance as it generates heat. Use of this product constitutes your understanding and acceptance that if not used properly, and or precautions/care is not taken where necessary, injury may result. Under such circumstances, no liability rests with the retailer, supplier, importer and manufacturer.

Due to the nature of this product, the element may become corroded over time. When this happens the appliance will no longer heat up and will need to be replaced.

The Recommended lifespan of this product is 1 year.

Know your Elektra Comfort Hot Water Bottle



(Colour of your hot water bottle may vary from that in the picture)

Charging up your Elektra Comfort Hot Water Bottle

- Unwind the charging cord and plug it into the power outlet.
- Place the Hot Water Bottle on a smooth, flat surface.
- Connect the adaptor to the charging port.
- Switch on the power at the outlet.
- The red light on the adaptor will light up.
- The Hot Water Bottle should take approximately 10 - 15 minutes to heat up to the maximum temperature.
- When the Hot Water Bottle has finished charging the red light on the adaptor will switch off.
- Carefully remove the adaptor from the charging port and place the Hot Water Bottle in to the Hot Water Bottle Cover.

N.B. Do not use the Hot Water Bottle while it is charging.

Plug

Never attempt to remove the plug, specifically when the Hot Water Bottle is hot.

Instructions for Cleaning

Hot Water Bottle cover:



Hot Water Bottle:



Should you need to clean the Hot Water Bottle:

- Wipe it down with a damp cloth and a small amount of non-abrasive cleaning agent.
- Never get the Hot Water Bottle wet.
- Do not use it if it is wet.

Storage Instructions

- The best place to store your Hot Water Bottle when not in use, is in the box you purchased it in.
- Do not place heavy objects on top of the Hot Water Bottle.
- Do not store near or use near sharp objects.
- Do not use any moth-proofing chemicals on your Hot Water Bottle.

After Sales Service

Your Elektra Comfort Hot Water Bottle is not user-serviceable.

If the charge light does not illuminate and the Hot Water Bottle does not heat up, check to see that:

1. You have followed the instructions properly.
2. The outlet supply is switched on.
3. The main supply fuse/circuit breaker has not blown/tripped.

If the appliance still does not work, contact the Service Centre.

If the light does illuminate and the Hot Water Bottle does not heat up, contact the Service Centre.

If the power supply cord or any wiring is damaged, or the Hot Water Bottle has been misused or damaged, stop use immediately and contact the Service Centre.

TEL: 011 393 1328 FAX: 011 393 1501 EMAIL: technical@sp-africa.com

Guarantee

Any defect affecting the functionality of the appliance which becomes apparent within one (1) year of its purchase, will be corrected by free repair or replacement, provided that the appliance has been used and maintained in accordance with the instructions, and has not been altered, abused or misused in anyway, and is accompanied with a Proof of Purchase to validate the age of the appliance.

Specifications

220-240V~ 50Hz 360W

The Environment

Please consider the environment when disposing of packaging.
Recycle wherever possible.

When you want to dispose of this appliance please do so responsibly, or contact us to assist with the disposal, or disposal advice.



**8 Palala Street, Protec Park, Terenure Ext. 42,
Kempton Park, South Africa, 1610**

Tel: 011 393 – 1328

Fax: 011 393 – 1501

www.sp-africa.com